



NOTE: VAPOR RETARDER RECOMMENDED ON WARM SIDE OF PANEL IN CLIMATES WHERE RETARDERS ARE CALLED OUT BY LOCAL CODE

NAIL OR STAPLE SIP TO R-STUD SPLINE WITH 8d @ 6" O.C. EACH SIDE STAGGERED  
 OPTION: FASTEN WITH #6 TYPE "S" DRYWALL SCREWS @ 6" O.C.

**1** PANEL CONNECTION W/  
**R-STUD**  
 1" = 1'-0"



EARTHCORE SIPS  
 1005 S. 120th  
 LAFAYETTE, CO 80026  
 888.299.3049  
 www.earthcoresips.com

This document is an instrument of service, and as such, remains the property of EarthCore SIPS. Permission for use of this document is limited and can be extended only by written agreement with EarthCore SIPS. COPYRIGHT 2011